

buddee

PORTABLE SUITCASE TURNTABLE FOR VINYL AND BLUETOOTH DEVICES



Thank you for purchasing a Buddee Portable Suitcase Turntable. For optimum performance and safety, read these instructions carefully before connecting, operating or adjusting this product.

Refer to this manual for future reference.

INTRODUCTION

Take your tunes with you using the Buddee Portable Suitcase Turntable. Pair any Bluetooth® enabled smartphone, MP3 player, tablet or other device wirelessly. Enjoy the latest hits or your favourite vinyl classics wherever you are through built-in stereo speakers. Plays 33 / 45 / 78 speeds.

FEATURES

- Built in speakers
- Vinyl Record Player
- Bluetooth® Wireless Audio
- Portable Carry Handle
- Charging via USB Input

PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- Turntable
- USB charging cable
- RCA Audio Cable
- Spare needle
- User manual

LOCATION OF CONTROLS


CHARGING

1. Connect the USB charging cable to the DC 5V charging port on the back of the turntable.
2. Connect the USB end of the USB charging cable into your computer or other USB charging device.
3. The LED charging indicator light will be GREEN while charging. It will turn off when the turntable is fully charged.

Note: The turntable should be charged for minimum 8 hours prior to the first use.

POWERING ON AND OFF

- Turn the Power/Volume dial to the right (MAX) to turn the unit ON. Turn it all the way to the left to turn the unit OFF.



DEVICE CONTROLS

1. Bluetooth®/Turntable switch
2. LED charging indicator light
3. LED Bluetooth® indicator light
4. LED power indicator light
5. ON/OFF Power/Volume dial
6. RCA right speaker output port
7. RCA left speaker output port
8. USB DC 5V charging port
9. 45 RPM Adaptor

ADJUSTING THE VOLUME

- Turn the Power/Volume dial to the left (MIN) to decrease the volume.
- Turn the Power/Volume dial to the right (MAX) to increase the volume.

Note: When playing music via Bluetooth® the volume can also be adjusted via the volume controls of the connected device.



Made in China

© Buddee Gear 2016. All rights reserved. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Buddee Gear Pty Ltd. is under license. Other trademarks and trade names are those of their respective owners.

PLAYING VINYL RECORDS

1. Place the record on the turntable and set the needle on the record.
2. Turn the Power/Volume dial to the right to turn the unit ON.
3. Move the Bluetooth®/Turntable switch to the Turntable position.

USING THE 45 RPM ADAPTOR

The 45 RPM adaptor allows you to play 45 RPM singles on 78 RPM spindle size turntables.

- Remove the 45 RPM adaptor and place it on the spindle.
- Place the record on the turntable. Make sure that the adaptor is secure.

USING AS A WIRED TURNTABLE

1. Turn the turntable ON.
2. Connect one red plug and white plug of the included RCA Audio Cable to the corresponding right and left speaker output ports on the back of the turntable.
3. Connect the other ends of the RCA audio cable to an external speaker system's input ports.
4. Select a song on your device and click PLAY to start playing your music.
5. Use the controls on your connected device to control music playback and volume.

Note: The Turntable's internal speaker volume can be increased or decreased when connected to a Bluetooth® enabled device. It will also adjust the volume to an external speaker when connected with the included RCA audio cable.

PLAYING WIRELESS MUSIC

To enjoy wireless music on your Portable Turntable, make sure you are connected to a Bluetooth® enabled device. Once connected press PLAY on your Bluetooth® device. When playback has begun, you can control the music with your connected device (with devices that have the AVRCP Bluetooth® profile).

PAIRING THE TURNTABLE via Bluetooth®

1. Turn the turntable ON.
2. Move the Bluetooth®/Turntable switch to the Bluetooth® position. The LED Bluetooth® indicator light will quickly flash.
3. Ensure that the turntable and the Bluetooth® enabled device you are trying to connect stay within 1 metre of each other while pairing.
4. Turn on Bluetooth® on your device.

Note: If a paired device is in range, the turntable will automatically connect when the Bluetooth®/Turntable switch is in the Bluetooth® position.

5. Select "BD-TTABLE-1" from the list of devices.
6. If required, enter the password 0000.
7. Once successfully paired, the LED Bluetooth® indicator light will flash BLUE slowly.

Note: If you would like to connect the turntable to another device, you must first unpair the unit from the currently paired device. In your device's Bluetooth® settings, select "BD-TTABLE-1", then select "unpair". When the turntable has been unpaired, it will automatically enter pairing mode.

TROUBLESHOOTING

- I have connected the Portable Turntable and my Bluetooth® device, but I cannot hear any music.
 1. Make sure your Bluetooth® device supports the A2DP profile.
 2. Turn up the volume on your Bluetooth® device.
 3. Unpair your device then follow the pairing instructions to re-pair.

- My Bluetooth® device is not able to pair with the Portable Turntable.
 1. Ensure the portable turntable is turned ON before beginning the pairing process.
 2. Ensure that the portable turntable and the Bluetooth® device you are trying to connect stay within 1 metre of each other while pairing.
 3. Move the Bluetooth®/Turntable switch to the Bluetooth® position. The LED Bluetooth® indicator light will quickly flash BLUE.
 4. Check that your device's Bluetooth® feature is turned ON.

- The Portable Turntable will not enter pairing mode.
 1. Ensure the portable turntable is turned ON before beginning the pairing process.
 2. Move the Bluetooth®/Turntable switch to the Bluetooth® position. The LED Bluetooth® indicator light will quickly flash BLUE.
 3. The turntable is now in pairing mode.