



## METALLIC BLUETOOTH® SPEAKER WITH DUAL STEREO SPEAKERS



### USER MANUAL

Thank you for purchasing a Buddee Metallic Bluetooth® Speaker. For optimum performance and safety, read these instructions carefully before connecting, operating or adjusting this product. Refer to this manual for future reference.

#### INTRODUCTION

Play music wirelessly, listen to FM radio or talk clearly on the phone with the Buddee Metallic Bluetooth® Speaker. In a compact and stylish design, this speaker delivers high quality stereo sound.

Charge your speaker from any USB compatible device. Works with all Bluetooth® enabled devices up to 10m or play your tunes via the auxiliary port or TF card slot.

#### FEATURES

- Bluetooth® audio
- USB charging
- AUX input
- Answer phone calls
- 10m wireless range
- TF card playback
- FM radio
- Dual speakers

#### PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- Metallic Bluetooth® Speaker
- Micro-USB charging cable
- 3.5mm AUX cable
- User manual


#### CHARGING

1. Insert the micro-USB end of the included cable into the charging port on the back of the Metallic Speaker.
2. Insert the USB end into a powered USB source such as a computer, laptop or USB wall charger. The charging indicator will light up red.

*NOTE:* Please fully charge the Metallic Speaker prior to first use.

#### POWERING ON

1. Slide the **power switch** to the **ON** position and the display will light up. The Metallic Speaker will enter **Bluetooth® mode**.
2. Slide the **power switch** to the **OFF** position to power down the Metallic Speaker.



1. AUX input
2. TF card input
3. Micro-USB charging port
4. Power switch (ON/OFF)

#### M MODE BUTTON

- Switch between Bluetooth® and FM radio modes.

#### ☎ PHONE BUTTON

- Answer/ hang up incoming phone calls.

#### ⏮ PREVIOUS/ VOLUME DOWN BUTTON

- Press to play a previous song or radio station.
- Press and hold to decrease volume.

#### ▶▶ PLAY BUTTON

- Press to play/pause a song.

#### ⏭ NEXT/ VOLUME UP BUTTON

- Press to skip forward a song or radio station.
- Press and hold to increase volume.



UN38.3



Made in China

© Buddee Gear 2017. All rights reserved. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Buddee Gear Pty Ltd. is under license. Other trademarks and trade names are those of their respective owners.

## BLUETOOTH® MODE

### PAIRING A DEVICE AND PLAYING AUDIO

1. After turning on the Metallic Speaker it will enter **Bluetooth® mode**. The LED indicator light will flash blue on the back of the unit, this indicates that the Metallic Speaker is waiting to be paired. *While pairing remain within one metre of the earphones.*

2. Using the controls on your *Bluetooth®* device, select **BD-MTLSPK-1** in your *Bluetooth®* settings menu. If your device requires a password, enter **0 0 0 0**. *Refer to the manual of your device for specific instructions on pairing and connecting Bluetooth® devices.*

3. Once pairing is successful, the LED display will stop flashing. Audio played through the connected *Bluetooth®* device will now be heard through the Metallic Speakers.

4. Use the controls on your connected device to select and begin to play audio. To **play/pause audio, skip songs** or **change the volume** use the controls on the top of the Metallic Speaker or the controls on your connected device.

## ANSWER PHONE CALLS

1. To accept a phone call, firstly pair your mobile with the Metallic Speaker via *Bluetooth®*. Once paired, press the **answer/hang up button** located on the top of the Metallic Speaker to accept an incoming call. You can now speak through the inbuilt microphone.

2. To end the call, press the **answer/hang up button** once more.

*NOTE: You can also use the controls on your mobile phone.*

## TF/ MICRO SD CARD MODE

1. Insert your TF or microSD card into the slot located on the back of the Metallic Speaker. The speaker will begin to play the mp3 files stored on the card.

2. Use the controls located on the top of the Metallic Speakers to **play/pause, adjust volume** or **skip songs** stored on your TF or microSD card.

## AUX LINE-IN MODE

1. Insert a 3.5mm AUX cable into the AUX port located on the back of the Metallic Speaker. Press the **mode button** until you reach the **AUX Line-In mode**.

2. Begin playing audio via your connected AUX device and the sound will be played through the Metallic Speaker.

## FM RADIO MODE

1. Plug in the micro-USB cable into the charging port on the back of the device. Press the **"M"** (mode) button twice to reach **FM radio mode**. The speaker will sound "radio mode". If the speaker sounds "*Bluetooth®* ready to pair", short press the **"M"** button again.

2. Scan through radio stations by pressing the **previous** and **next buttons**.

3. For **auto-tuning**, press the **pause button** once. The speaker will now search for radio channels automatically.

*NOTE: For radio operation, ensure the micro-USB cable is plugged in (the USB end does not need to be connected) to act as an aerial. The AUX cable (included) can also be used as an aerial by connecting one end of the 3.5mm AUX cable to the back of the unit via the AUX Line-In port.*

## TECHNICAL SPECIFICATIONS

Input: DC5V

Output Power: 3W x 2 (RMS)

Battery: Litlon 1200mAh

Battery life: 4 hours at 80% volume

Frequency: 50Hz-20KHz

Input Sensitivity: 400mV

Signal to Noise Ratio: ≥88Db

External Magnetic Horn: 40mm x 2

*Bluetooth®*: Version 3.0.