

AUDIO CONVERTER DIGITAL TOSLINK TO ANALOGUE

USER MANUAL

Thank you for purchasing a Buddee Audio Converter. For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

INTRODUCTION

This Digital to Analog Audio Converter is designed for either home or professional audio switching. It converts Coaxial or Toslink digital audio signals to analog L/R audio and available for connection to an external device such as an amplifier via standard RCA-style jacks. This Converter is small in size and quite easy to install.

FEATURES

- Converts Coaxial or Toslink digital audio signals to analog L/R audio
- Supports sampling rate at 32, 44.1, 48 and 96 KHz.
- 24-bit S/PDIF incoming bit stream on left and right channels
- Provides electromagnetic-noise-free transmission.
- Easy to install and simple to operate.

PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- Main unit (Digital to Analog Audio Converter).
- 5V DC Power Supply
- Optical cable 300mm
- User's Manual

SPECIFICATIONS

Signal Inputs/Output

Connector

Input audio connector......Toslink, 1XRCA(Coaxial)

Output audio connector.....2XRCA(R/L)

Sampling rate......32, 44.1, 48 and 96 KHz

Mechanical

Size(LxWxH)......51x41x26mm

Weight (Net).....78g

Warranty

Limited Warranty......1 Year Parts and Labor

Environmental

Operating Temperature.....0 °C to +70°C

Operating Humidity......10% to 85% RH (no condensation)

Storage Temperature.....-10°C to +80°C

Storage Humidity......5% to 90% RH (no condensation)

Power Requirement

External Power Supply.....DC 5V 1A
Power Consumption......0.5 watts (max)

Regulatory Approvals

Converter Unit......FCC,CE,UL Power Supply.....UL,CE,FCC

Accessories Adapter

AC Power Adapter......US standard, UK standard and so on

User Manual.....English Version

CONNECTION & OPERATION

Before installation, please make sure all devices you wish to connect have been turned off.

- 1) Connect the audio source device to the Converter using appropriate Toslink or Coaxial cables.
- 2) Connect the AV Receivers or Amplifiers to the Converter using appropriate L/R cable.
- 3) Insert the DC side of 5v power supply into the converter and then connect the AC side of the power supply into the wall outlet.

Note: When connected to the Toslink and Coaxial cables at the same time, the product will give priority to Toslink input.

Attention: Insert / Extract cable gently.

